




Interchangeable, NI Not Interchangeable, >> New for Old, << Old for New

No.	Part No.	Part Name	Qty	IC	Serial No./PIN	Remarks	Kg
010	TC050-42010	TANK,FUEL	1				5.0
020	3A011-04290	ASSY CAP,FUEL TANK	1		<=9RZ999		0.06
020	3A011-04294	ASSY CAP,FUEL TANK	1	>>	>=9S0001		0.06
030	34150-35240	SPONGE	1				0.001
040	3A011-04300	GASKET	1		<=9RZ999		0.015
040	3A011-04302	GASKET	1	>>	>=9S0001		0.015
050	34150-35180	GASKET	1				0.001
060	13582-41680	PLATE,F.TANK.CAP	1				0.008
070	T0430-42020	TRAY,FUEL	1				0.025
080	TC050-42072	PIPE	1				0.065
090	6C040-54780	CLAMP	1		<=AHZ999		0.005
090	09318-88220	CLAMP,HOSE	1	>>	>=AJ0001		0.006
090	09318-88200	CLAMP,HOSE	1	>>	>=AL0001		0.004

== Interchangeable NI Not Interchangeable >> New for Old << Old for New

No.	Part No.	Part Name	Qty	IC	Serial No./PIN	Remarks	Kg
100	TC050-42140	PLATE, FUEL TANK	1				0.095
110	01754-50820	BOLT,FLANGE	2				0.015
120	TC050-42160	BASE,FUEL TANK	1				3.8
130	01774-51020	BOLT,FLANGE	2				0.02
140	01754-50812	BOLT,FLANGE	2				0.008
150	TC050-42113	SUPPORT,FUEL TANK	1				9.2
160	TC050-42122	STAY,FUEL TANK LH	1				0.48
170	TC050-42150	STAY,FUEL TANK RH	1				0.11
180	01754-50816	BOLT,FLANGE	4				0.011
190	02751-50080	NUT,FLANGE	2				0.006
200	01133-51025	BOLT	2				0.023
210	04013-50100	WASHER,PLAIN	2				0.004
220	TC050-42022	CLAMP,FUEL TANK FR.	1				0.45
230	TC050-42032	CLAMP,FUEL TANK REAR	1				0.46
240	TC050-42040	CUSHION	2				0.1
250	02552-50080	LOCKNUT	4				0.005
260	04013-50080	WASHER,PLAIN	4				0.002
270	TC050-42050	CUSHION,RUBBER	1				0.1
280	TC050-42060	CUSHION,RUBBER	2				0.08
290	3A011-04222	CUSHION	2				0.04
300	TC050-42080	INSULATION,HEAT	1				0.06
310	TC050-42090	INSULATION,HEAT	1				0.04
320	TC050-42260	GROMMET,SHUTTER	1				0.01
330	37150-34460	CLANP,CORD	1				0.004
340	TC059-44130	STAY,BRAKE SWITCH	1		<=51215		0.0
340	TC059-44133	STAY,BRAKE SWITCH	1	>>	>=51216		0.098